

dacor®

The Life of the Kitchen.®


PARTS CATALOG

DECT365 Electric Cooktop

Page #	Description
2	Chassis Assembly
3	Chassis Parts
4	Control Panel

Revised 04-04-2012


DECT365 Cooktop - Chassis Assembly



DECT365 Cooktop - Chassis Parts

Item	Description	Part #
1	Cooktop Glass	105742
2	Conduit and Power Wiring Harness	105744
3	Hot Surface Indicator Light Assy	105750
4	Clamp Bracket with Screws	105753
5	Seal, Control Panel	105755
6	Seal, Foam Tape (countertop)	105756
7	Burner Box (chassis)	105760
8	Reflector	105761
9	Heat Shield	105762
10	Bracket for Hot Surface Indicator Light Assy	105764
11	Knob	105765
12	Element Support	105766
13	Element Bracket	105767
14	Spacer, Chassis	105768
15	Seal, Knob Hole	105757
16	Heating Element, 6 Inch (single)	105746
17	Heating Element, 7 Inch (single)	105747
18	Heating Element, 9 Inch (dual)	105748
19	Heating Element, 11 Inch (dual)	105754
-	Wiring Harness (Not Shown)	105739
-	Scraper, Ceran (Not Shown)	105740

DECT365 Cooktop - Control Panel



Item	Description	Part #
1	Control Panel Chassis	105758
2	Rheostat, Single Element	105751
3	Rheostat, Dual Element	105752
4	Terminal Block	105745