



The Life of the Kitchen.®

PARTS CATALOG

ECPD/ECPS Wall Ovens

IMPORTANT: This product may have some parts that are **No Longer Available (NLA)**. If the part you need is no longer available, please contact Dacor for a possible solution:

DACOR CARES PROGRAM NLA Part Locator Service

Customer Contact Number:

(800) 793-0093 ex. 2813
Hours: 6:00 AM - 5:00 PM Pacific Time

Service Agent/Technician Contact Number:

(800) 793-0093 ex. 3814
Hours: 7:00 AM - 4:00 PM Pacific Time

Web Inquiries: www.dacor.com/dacorcares

Email Inquiries: dacorcares@dacor.com


Please provide the following information:

- Your name and phone number
- Product model number
- Product serial number
- The part number(s) you need

Page #	Description
2	Bezel/Membrane Assembly
3	Door Assembly
4	Single Oven Chassis
5	ECPS Double Oven Bottom Cell Components
6	ECPD Double Oven Bottom Cell Components
7	Double Oven Chassis
8	Parts List


Revised 02-04-2015

ECPD/ECPS Bezel/Membrane Assembly



Part no longer available? Contact Dacor: (800) 793-0093 ex. 3814


ECPD/ECPS Wall Oven Door Assembly




Part no longer available? Contact Dacor: (800) 793-0093 ex. 3814




ECPS Single Wall Oven Chassis Assembly



ECPS Double Oven Bottom Cell Components



ECPD Double Oven Bottom Cell Components



Part no longer available? Contact Dacor: (800) 793-0093 ex. 3814



ECPS/ECPD Wall Oven Parts List

Item	Description	Parts Numbers - 27-Inch			Parts Numbers - 30-Inch		
		ECPS127	ECPS227	ECPD227	ECPS130	ECPS230	ECPD230
1	Baffle (Non Convection)	NA	26545BP	NA	NA	26545BP	NA
2	Baffle, Air (Lower)	NA	26599	26599	NA	26634	26634
3	Baffle, Convection	26595BP	26595BP	26595BP	26655BP	26655BP	26655BP
4	Baffle, Rear (Lower)	NA	26608	26608	NA	26608	26608
5	Backing Panel, Vented	26689B	26689B	26689B	26435B	26435B	26435B
6	Blade, Convection Fan	82651	82651	82651	82651	82651	82651
7	Block, Terminal	82151	82151	82151	82151	82151	82151
8	Blower, Cooling	82986	82986	82986	82986	82986	82986
9	Bracket, Conduit Mounting	26584	26584	26584	26584	26584	26584
10	Bracket, Conduit Mounting	26584	26661	26661	26584	26661	26661
11	Bracket, Stiffener	26606	26606	26606	26606	26606	26606
12	Bracket, Oven Support	NA	26611	26611	NA	26611	26611
13	Brkt, Bezel Mounting (Left)	86676	86676	86676	86676	86676	86676
14	Brkt, Bezel Mounting (Right)	86675	86675	86675	86675	86675	86675
14A	Brkt, Terminal Block	NA	26605	26605	NA	26605	26605
14B	Block, Terminal	NA	83556	83556	NA	83556	83556
14C	Bushing, Plastic	NA	83056	83056	NA	83056	83056
15	Bulb, Light (40W)	82089	82089	82089	82089	82089	82089
16A	Case Top	26581	26581	26581	26629	26629	26629
16B	Case Back	26596	26596	26596	26632	26632	26632
16C	Case Bottom	26597	26597	26597	26633	26633	26633
17	Case, Side (Left)	27454	27454	27454	27454	27454	27454
18	Case, Side (Right)	27453	27453	27453	27453	27453	27453
19	Cover Plate	26547	26547	26547	NA	26547	NA
20	Cell, Oven	27450BP	27450BP	27450BP	27462BP	27462BP	27462BP



Part no longer available? Contact Dacor: (800) 793-0093 ex. 3814

ECPS/ECPD Wall Oven Parts List

Item	Description	Parts Numbers - 27-Inch			Parts Numbers - 30-Inch		
		ECPS127	ECPS227	ECPD227	ECPS130	ECPS230	ECPD230
21	Conduit, CSA	26420	26430	26430	26420	26430	26430
22	Conduit, UL	26420	26430	26430	26420	26430	26430
23	Cover Plate	26560	26560	26560	26560	26560	26560
24	Cover, Back	27471	27472	27472	27476	27477	27477
25	Cover, Exhaust Duct	26580	26612	26612	26658	26659	26659
26	Cover, Top Front	26601	26601	26601	26636	26636	26636
27	Cover, Top Rear	26600	26600	26600	26635	26635	26635
28	Duct, Transition	27455	27455	27455	27455	27455	27455
29	E. R. C.	62692	62681	62681	62692	62681	62681
30	Elbow, Conduit, 1/2	82196	82196	82196	82196	82196	82196
31	Elbow, Conduit, 3/4	82195	82195	82195	82195	82195	82195
32	Element, Bake	82989	82989	82989	86745	86745	86745
33	Element, Broil	82817	82817	82817	82817	82817	82817
34	Element, Convection	82377	82377	82377	82377	82377	82377
35	Exhaust Duct	27427	27456	27456	26656	26657	26657
36	Exhaust Duct Divider	27428	27457	27457	27428	27457	27457
37	Exhaust Tube	82695	82695	82695	82240	82240	82240
38	Filter, Convection	82891	82891	82891	82891	82891	82891
39	Fuse Box Assembly	12400	12401	12401	12401	12401	12401
40	Fuse Holder 15 Amp	86674	86674	86674	86674	86674	86674
41	Fuse Holder, 30 Amp	82506	82506	82506	82506	82506	82506
42	Fuse, 15 Amp	83110	83110	83110	83110	83110	83110
43	Fuse, 30 Amp	83112	83112	83112	83112	83112	83112
44	Grille, Air Intake	26609B	26609B	26609B	26638B	26638B	26638B
45	Grille, Exhaust (prior to SN VD824000)	86701B,R,S	86702B,R,S	86702B,R,S	86703B,R,S	86705B,R,S	86705B,R,S
	Grille, Exhaust	13123B,R,S	13123B,R,S	13123B,R,S	13124B,R,S	13124B,R,S	13124B,R,S
46	Harness, ERC to Relay	82445	82445	82445	82445	82445	82445
47	Harness, ERC to Relay	NA	82446	82446	NA	82446	82446

Part no longer available? Contact Dacor: (800) 793-0093 ex. 3814



ECPS/ECPD Wall Oven Parts List

Item	Description	Parts Numbers - 27-Inch			Parts Numbers - 30-Inch		
		ECPS127	ECPS227	ECPD227	ECPS130	ECPS230	ECPD230
48	Harness, Oven Light (Lower, not shown)	NA	82816	82816	NA	82816	82816
49	Harness, Oven Light (Upper, not shown)	82815	82815	82815	82815	82815	82815
50	Harness, Sensor/Lock (Lower)	NA	82449	82449	NA	82449	82449
51	Harness, Sensor/Lock (Upper)	82447	82448	82448	82447	82448	82448
52	Hinge, Roller	82851	82851	82851	82851	82851	82851
53	Door Latch Kit	701582	701582	701582	701582	701582	701582
54	Lead Wire Kit	86672	86670	86670	86672	86670	86670
55	Lead Wire Kit	86673	86671	86671	86673	86671	86671
56	Light Service Kit	701750	701750	701750	701750	701750	701750
57	Motor, Convection	82647	82647	82647	82647	82647	82647
58	Mounting Brkt Lower Fan	NA	26607	26607	NA	27475	27475
59	Mounting Plate, Conv. Mtr.	27470	27470	27470	27470	27470	27470
60	Mounting Plate, Latch	Must replace entire latch assembly, order item # 53					
61	Plate, Bottom Exhaust	26602	26602	26602	26637	26637	26637
62	Plate, Relay Mounting	26604	26604	26604	26604	26604	26604
63	Relay Board (Main)	82127	62439	62439	82127	62439	62439
64	Relay Board (Lower)	NA	82985	82994	NA	82985	82994
65	Sensor, Oven Temperature	86663	86663	86663	86663	86663	86663
66	Smoke Eliminator	82826	82826	82826	82826	82826	82826
67	Sub Chassis	27452	27452	27452	27463	27463	27463
68	Support Rack	82650	82650	82650	82650	82650	82650
69	Thermal Cutout (Lower)	NA	82987	82987	82987	82987	82987
69	Thermal Cutout (Upper)	82987	82987	82987	82987	82987	82987
70	Trim, Left	27467 B/R	27469 B/R	27469 B/R	27467 B/R	27469 B/R	27469 B/R
71	Trim, Right	27466 B/R	27468 B/R	27468 B/R	27466 B/R	27468 B/R	27468 B/R
72	Membrane touchpad with logo, black	62038B	62207B	62208B	62038B	62207B	62208B
	Membrane touchpad with logo, white	62211R	62206R	62216R	62211R	62206R	62216R
73	Bezel Assembly	86324 B/R/S	86324 B/R/S	86324 B/R/S	86328 B/R/S	86328 B/R/S	86328 B/R/S



Part no longer available? Contact Dacor: (800) 793-0093 ex. 3814

ECPS/ECPD Wall Oven Parts List

Item	Description	Parts Numbers - 27-Inch			Parts Numbers - 30-Inch		
		ECPS127	ECPS227	ECPD227	ECPS130	ECPS230	ECPD230
74	Door Handle Assy. (W/Logo)	13122	13122	13122	13130	13130	13130
	Door Handle Assy. (No Logo)	13143	13143	13143	13144	13144	13144
	Door Handle Assy. (No Logo)	13097 B/R	13097 B/R	13097 B/R	13127 B/R	13127 B/R	13127 B/R
75	Trim, Door Edge (Left)	26370	26370	26370	26370	26370	26370
	Trim, Door Edge (Left)	26489 B/R	26489 B/R	26489 B/R	26489 B/R	26489 B/R	26489 B/R
76	Trim, Door Edge (Right)	26371	26371	26371	26371	26371	26371
	Trim, Door Edge (Right)	26490 B/R	26490 B/R	26490 B/R	26490 B/R	26490 B/R	26490 B/R
77	Tape, Double Sided	83573	83573	83573	83573	83573	83573
78	Door Glass Mounting Frame	27496 B/R	27496 B/R	27496 B/R	27497 B/R	27497 B/R	27497 B/R
	Door Glass Mounting Frame, SS	27122B	27122B	27122B	27088B	27088B	27088B
79	Gasket, Door	82691	82691	82691	82124	82124	82124
80	Assy, Door Skin	86121	86121	86121	86122	86122	86122
	Door Glass (Colored Models)	82693 B/R	82693 B/R	82693 B/R	82216 B/R	82216 B/R	82216 B/R
81	Glass, Inner "Window Pack"	82954	82954	82954	82954	82954	82954
82	Heat Shield	26575	26575	26575	26640	26640	26640
86	Hinge, Door	82508	82508	82508	82508	82508	82508
87	Instruction Plate (not shown)	82698	82698	82698	82698	82698	82698
88	Insulation	13165	13165	13165	13167	13167	13167
89	Liner, Inner	27423BP	27423BP	27423BP	27459BP	27459BP	27459BP
90	Liner, Outer	86744	86744	86744	86746	86746	86746
91	Shield, Inner Door	26575B	26575B	26575B	26574B	26574B	26574B
92	Thermocord	83425	83425	83425	83425	83425	83425
	"J" Trim Window Pack	82790BP	82790BP	82790BP	82790BP	82790BP	82790BP
93	Shield, Left	26577	26577	26577	26577	26577	26577
94	Shield, Right	26576	26576	26576	26576	26576	26576
95	Tape, Double Sided	83577	83577	83577	83577	83577	83577
99	Rack, Convection	62137	62137	62137	62139	62139	62139
100	Rack, Non Convection	NA	62138	NA	NA	62140	NA



Part no longer available? Contact Dacor: (800) 793-0093 ex. 3814

ECPS/ECPD Wall Oven Parts List

Screws and Fasteners		
Item	Description	Parts Number
F1	Screw #10 X 3/8	83023
F2	Screw #8 X 3/8 Truss	83024
F3	Screw #10 X 3/4	83026
F4	Screw #8 X 3/8 Wafer	83263
F5	Screw #6 X 3/8 Truss	83570
F6	Screw #8 X 3/8 Enamel	83534
F7	Washer, Fiber	83555
F8	Screw #8 X 3/4 Pan	83010
F9	Screw #8 X 3/8 Enamel	83534
F10	Screw #8 X 3/8	83019
F11	Screw	83569
F12	Screw #10 X 1/2 Truss	83022
F13	Screw 8/32 X 1/2 Pan	83336
F14	Screw #8 X 3/8 Wafer	83571
F15	Screw 8/32 X 1/2 Pan	83572
F16	Screw 5 X 10 MM Socket	83553
F17	Washer #10 Tooth Lock	83340
F18	Screw #8 X 5/8 Pan	83042
F19	Nylon Standoff	83538